

Project Proposal: Comparative analysis of
Gene Finding tools when applied to
Trichoderma genomes

Connor Burbridge¹

¹USask NSID: cbe453 , USask ID no. 11162928 , Supervisors:
Dave Schneider & Tony Kusalik,

February 15, 2023

Contents

1	Pre-work	3
1.1	Existing selection of Genome Assemblies	3
1.2	Assembly	3
1.3	Repeat Masking	5
2	Software Installation	5

1 Pre-work

1.1 Existing selection of Genome Assemblies

Comparison of several different *Trichoderma* genomes is important in the context of gene finding tools as different gene finding tools will find different genes and understanding how these tools behave in the context of different *Trichoderma* genomes could prove useful for those looking to find genes in similar fungal genomes in the future. To accent the processing for genomes of interest, those being DC1 and Tsht20, we should include other previously assembled *Trichoderma* assemblies. Currently selected genomes include *Trichoderma reesei*, *Trichoderma harzianum*, and *Trichoderma virens*?, with *Trichoderma reesei* being the 'reference' in this case, as it is well studied and there are several patents involving it's use as an organism for production of compounds such as antibiotics in industrial applications.

1.2 Assembly

The foundation of this project is based on the sequencing of two novel *Trichoderma* strains identified in prairie regions of Canada (Alberta and Saskatchewan). To assemble these genomes, a hybrid assembly process was used, following default assembly parameters with MASuRcA, which utilizes the Flye assembler if both Nanopore and Illumina data are used as inputs, which are the inputs in this case. The next paragraph describes the process of working with MASuRcA.

MASuRcA 4.0.3 was run using the Compute Canada software stack available on Copernicus. Prior to loading the MASuRcA environment, the GCC/9.0 and StdEnv/2020 modules must be loaded first. This version of the software is not ideal, but the Anaconda installation of version 4.0.9 consistently failed, even in a fresh environment. Building the software from scratch is a potential option. In addition to this difficulty, the assemblies were performed in the p2irc_rsmi scratch space on Copernicus as I was encountering permissions issues when trying to run the assembly in the Roots datastore. I don't know exactly why (microsoft permissions problems from datastore?, but there were permission issues associated with scripts being copied to datastore as part of the assembly process. All assembly materials were copied back to datastore after assembly.

Initially, a configuration file must be generated to run MASuRcA with the

optimal combination of assembly tools for the data supplied (Flye + polishing). Running MASuRcA from the commandline tool utilizes the CABOG celera-based assembler, which is noted as being slower and results in an assembly with similar or worse quality than one using Flye.

To generate the config file, run the following: `masurca -g config.txt`

The config file was then altered to provide input file, options and allowable number of threads for assembly. All other assembly parameters were left untouched. Insert lengths for the Illumina read data used the recommended values (stated to work for most Illumina reads), although these could be modified with input from Brendan. The config files for both assemblies are available in the asseblly directories.

To generate the assembly.sh script, run: `masurca config.txt`

Once the assembly.sh script is generated, execute the assembly using: `./assemble.sh`

Final assemblies are placed in directories with the prefix `flye.mr.*` Quast analysis of the genomes was also performed, with the output being placed in directories named `quast` within the assembly directory.

To run Quast: `quast -o ./ -t 16 assembly-file.fasta`

In an attempt to produce higher quality assemblies of DC1 and Tsth20, It has been suggested that I try a set of tools call NextDenovo and NextPolish as they have produced excellent assemblies based on previous experience from supervisors.

Installation of NextDenovo was straightforward. Simply download the compressed tar file from their website and unpack it. NextDenovo requires Python versions 2 and 3 along with a package called parallel to aid in parallel processing of datasets. I installed parallel using pip in the bioinformatics conda environment in the scracth space of Copernicus.

Initial attempts to run the example dataset resulted in some permissions errors, which I have encountered with other tools in the past. Thank you datastore. To remedy this, I copied the installation to RSMI's scratch space on Copernicus. Once the appropriate permissions were given to run nextDenovo, I was able to run the example dataset assembly without issue. Future assemblies of DC1 and Tsth20 will be performed in this scratch space to avoid permissiions issues and results will be copied to datastore.

1.3 Repeat Masking

In order to evaluate the performance of gene finding tools in repetitive or low complexity regions in the context of *Trichoderma* genomes, we must first identify said regions in the genomes considered. To do this, RepeatMasker has been selected as a tool to identify repeat regions based on a fungal subset of the Dfam database by specifying the fungo species tag to RepeatMasker when running the program. The program was configured with options to produce several output formats for each genome considered, which will allow for more informative downstream analysis of results. All commands for repeat masking are located within the processing directory for each strain/genome.

The Installation procedure was somewhat in-depth, requiring RepeatMasker configuration, which itself requires downloading an appropriate repeat database (Dfam in this case, included with RepeatMasker), installation of Tandem Repeat Finder (TRFM) and installation of a sequence search tool, for which I chose HMMER from the list of potential tools as I am generally familiar with its use.

General command for running RepeatMasker: `/datastore/Roots/Connor/masters/software/repeatmasker -pa 10 -a -small -species fungi -html -gff -dir ./ path-to-genome/genome.fasta`

2 Software Installation

Currently, GeneMark-ES and Braker2 have been difficult to install and have not been successfully installed yet.

GenomeThreader installed successfully via Anaconda in the bioinformatics environments on cnic-gifs-aio-18001 (rsmi01).

3 Gene Finding

Now that we have covered information about assembling and installation of these tools, we can cover the gene finding portion of this work.

To begin, I ran GeneMark-ES as it requires no prior information or alignments in order to run. In this case GeneMark-ES has an option specifically for fungal genomes, which I chose to use in this case.